

CHINA TOILET BOWL LEAKING WATER

1. What is it? Toilet Flush Valve Seal
2. Symptoms or Problem? Toilet bowl water level drops or odors from tank
3. Location: Just below bowl when flush ball valve open
4. Replacement Availability: For Dometic 310 Series or Sealand Traveler Toilet Flush Valve Seal Part# 385311658 – Amazon or any RV parts dealer
5. Ease of Replacement: DIY; Directions included with part but the flush valve will need to remain open. Turn water off. Removing seal easy, replacing takes some patience. Most importantly CLEAN the rim where seal was positioned before replacing. Build-up will cause it to leak. Try cleaning and replacing original seal if in good condition as it may resolve the issue and you'll have a spare just in case! Recommend using a product like Thetford Toilet Seal Conditioner.

